4494 GIRLS' ENERGY JACKET

GIRLS' SIZES **S-XL**

:: Moisture Wicking Technology
:: 7 Bold & bright color combinations
:: Coordinates with Girls' Energy Pant, style 4496

MOISTURE WICKING **tech**nology

Stand-up collar

Single needle top stitching

Tri-color design

Full zip design

Side-seam zippered pockets for secured storage

Open cuffs

Curved open bottom hem

BACK IMAGE

CHARLES RIVER APPAREL®

COMFORT & CONVENIENCE

:: Made exclusively with TopShield™ moisture management treatment. This hi-tech treatment applied to the fabric wicks moisture away from your body, keeping you comfortable and dry

:: 100% Polyester tricot brushed on the inside for softness

:: Semi-fitted for a stylish silhouette

:: Curved hem for unrestricted movement and extra coverage on lower back

:: Side pockets zip upward, protecting contents from inadvertently falling out. Self lined for less bulk

:: Suitable for school & team wear, fitness center/gym, or cheer/dance/gymnastics wear

:: Also available in Women's, style 5494

FABRIC

100% Polyester Brushed Tricot, 210 gsm/sq. mt.

SIZES

Youth Girls' sizes S–XL

COLORS

314 Black/Hot Pink/White, 315 Black/Red/White, 318 Black/Orange/White, 344 Navy/Red/White, 349 Navy/Gold/White, 361 Red/Black/White, 378 Royal/Black/White

GARMENT CARE

Machine wash cold. Gentle cycle with like colors. Line dry. Do not bleach. Do not iron. Do not dry clean.

314 BLACK + HOT PINK + WHITE

315 BLACK + RED + WHITE

318 BLACK + ORANGE + WHITE

344 NAVY + RED + WHITE

349 NAVY + GOLD + WHITE

361 RED + BLACK + WHITE

378 ROYAL + BLACK + WHITE

ENERGY JACKET GIRLS' 4494	S	M	L	XL	TOLERANCE
BODY LENGTH measure from neck (cb neck)	18½	20	21½	23	½ +/-
ACROSS SHOULDER measure from back	11¾	12¼	13	13¾	½ +/-
CHEST WIDTH 1 inch below armhole	15	16	17½	19	½ +/-
WAIST WIDTH	14¾	15¾	17¼	18¾	½ +/-
BOTTOM OPENING WIDTH RELAXED	16	17	18½	20	½ +/-
SLEEVE LENGTH FROM CB long (include cuff)	24	26	28	30	½ +/-

KEY TO COMMONLY ABBREVIATED SPEC INFORMATION (ALL MEASUREMENTS ARE IN INCHES)

CB = CENTER BACK

CHEST 1 INCH DOWN = MEASURE THE FRONT OF THE GARMENT 1 INCH DOWN FROM THE ARMHOLE

1/2 = MEASURE ONLY THE FRONT OF THE GARMENT, THEN DOUBLE THAT MEASUREMENT TO GET THE TOTAL CIRCUMFERENCE

RELAXED = DO NOT STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, SIMPLY LEAVE THE ELASTIC RELAXED

STRETCHED = STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, MEASURE STRETCHED

CHARLES RIVER
A P P A R E L®